

# USER MANUAL

QG65D J1939 Dynamic Inclinator (Type JA)

V1.0, Dec-21



**DIS Sensors bv**

Oostergracht 40

3763 LZ Soest | The Netherlands

**T** +31 (0)35 - 603 81 81

**M** [info@dis-sensors.com](mailto:info@dis-sensors.com)

**W** [www.dis-sensors.com](http://www.dis-sensors.com)

## Contents

1.	Safety information .....	2
1.1.	Intended use.....	2
1.2.	Incorrect use.....	2
1.3.	Sensor defective .....	2
2.	About this manual .....	3
2.1.	Intended use.....	3
2.2.	Symbols used in the text .....	3
2.3.	Copyright .....	3
2.4.	Document revision control.....	4
3.	Quick reference .....	5
4.	Installation guide.....	6
4.1.	Mechanical drawing .....	6
4.2.	Mounting.....	6
4.3.	Connection .....	7
4.4.	CAN termination.....	8
5.	Technical data .....	8
6.	Functional description.....	9
6.1.	Dynamic inclination measurement principle.....	9
6.2.	Measuring axis and direction .....	10
6.3.	Signal processing .....	11
6.4.	Boot-up procedure .....	12
6.5.	Output format .....	13
6.6.	Sensor configuration (PGN 61184).....	15
6.7.	Load factory default settings.....	16
6.8.	Zero adjustment .....	17
6.9.	Firmware management .....	19
7.	SAE J1939 specification .....	20
7.1.	PDU (Protocol Data Unit).....	20
7.2.	CAN-ID (CAN Identifier) .....	20
7.3.	PGN (Parameter Group Number) .....	21
7.4.	SPN (Suspect Parameter Number) .....	23
7.5.	NAME and ACM (PGN 60928).....	23
8.	Object overview .....	25
9.	Configuration examples .....	27
9.1.	Change device address .....	27
9.2.	Change baud rate .....	27
9.3.	Enable/Disable PGNs .....	28
9.4.	Save changes to the sensor .....	29
9.5.	Restore factory default.....	29
9.6.	Read vendor ID .....	29
9.7.	Zero adjustment .....	30
10.	Abbreviations and definitions .....	31
11.	Normative references .....	31

## 1. Safety information

### 1.1. Intended use

The QG65D J1939 Dynamic Inclinometer is a MEMS-based inclination sensor with J1939 interface. This device provides precise and reliable inclination measurement in both static and dynamic conditions. The use of this device in a machine or system is permitted only under the following conditions:

- The user is trained and competent in the integration and use of inclination sensors in machinery.
- The user is familiar with the contents of both the datasheet and user manual.
- The user has a full understanding of CAN and J1939.
- The device is used within the specified environmental conditions.
- The device is properly configured for its intended use.
- The device is mounted correctly as described in the datasheet and user manual.
- The device data is expressly not interpreted as safety data, except when used redundantly in a control system that is designed and tested for cross-check functionality between the primary and redundant devices.

### 1.2. Incorrect use

- Use of non-standard CAN cables.
- Device mounted incorrectly.
- Zero adjustment outside the specified range.
- Incorrect or absent CAN bus termination.
- Device used outside the specifications.

### 1.3. Sensor defective

The sensor is considered “defective” when

- No CAN output can be detected.

In the event of uncertainty, contact the distributor or manufacturer. Any unauthorised modification or unapproved use will void both the warranty and any liability on the part of the manufacturer.

## 2. About this manual



### 2.1. Intended use

This manual applies solely to the QG65D J1939 dynamic inclinometer (Type JA) with the following model designations:

- QG65D-KIXv-360H-CANJ-C(F)M-UL — 1 axis,  $\pm 180^\circ$ , vertical mounting, high accuracy
- QG65D-KDXYh-090H-CANJ-C(F)M-UL — 2 axes,  $\pm 90^\circ$ , horizontal mounting, high accuracy
- QG65D-KDXYh-030H-CANJ-C(F)M-UL — 2 axes,  $\pm 30^\circ$ , horizontal mounting, high accuracy
- QG65D-KIXv-360-CANJ-C(F)M-UL — 1 axis,  $\pm 180^\circ$ , vertical mounting, std. accuracy
- QG65D-KDXYh-090-CANJ-C(F)M-UL — 2 axes,  $\pm 90^\circ$ , horizontal mounting, std. accuracy
- QG65D-KDXYh-030-CANJ-C(F)M-UL — 2 axes,  $\pm 30^\circ$ , horizontal mounting, std. accuracy

DIS product code can be identified [here](#).

### 2.2. Symbols used in the text

- h Subscript for hexadecimal values.
- d Subscript for decimal values.
-  Caution that indicates either potential damage to the sensor or explains how to avoid a problem.
-  Important information.
- Cross-reference

### 2.3. Copyright

© Copyright 2021 DIS Sensors bv.

This manual is subject to change without notice.

All rights according to the copyright remain explicitly reserved for DIS Sensors bv.

## 2.4. Document revision control

Version	Date(y-m-d)	Revision
V1.0	2021-12-03	1 <sup>st</sup> release

Table 1 - Document revision

### 3. Quick reference

#### General

- 1-axis  $\pm 180^\circ$  and 2-axes  $\pm 30^\circ/\pm 90^\circ$  dynamic inclinometer
- Output type: SAE J1939
- Internal sample rate MEMS: 1000Hz
- Dynamic inclination application limitations: max. acceleration 1.5 g, max. angle rate  $500^\circ/\text{s}$
- Approved for automotive use, approval number: E4-10R-05-4662

#### CAN, J1939

- CAN interface: CAN2.0 A and B (complies with ISO11898-1&2)
- Application layer: SAE J1939 (29-bit CAN identifier)
- CAN bus bit rate: 250 kbit/s default, optional 500kbit/s
- Device address:  $128_d$  ( $80_h$ ) default
- PGN cycle time: 100ms default
- Output data: PGN 65280 (Inclination), PGN 65283 (Acceleration)
- Sensor configuration: PGN 61184 ( $EF00_h$ )
- Zero adjustment via object  $300F_h$
- Negative values: two's complement
- Byte-sequence on CAN bus: little-endian (least significant byte first)

## 4. Installation guide

### 4.1. Mechanical drawing




Figure 1 - Mechanical drawing of QG65D with a male M12.

### 4.2. Mounting

- Use the 4 screws provided (M5x25 mm zinc plated steel Pozidrive pan head screws with self-tapping PZ DIN7500CZ) to mount the device.
- If a software zero adjustment is impossible or undesirable, DIS provides an optional reference solution of replacing 2 of the provided screws with 2 optional 4mm  $\varnothing$  positioning pins, which can serve as mechanical reference.
- Tightening torque max. 2.5 Nm. A higher torque can cause damage to the housing or the internal electronics.
- Fix the sensor to a perfectly flat surface.
- A 1-axis inclinometer must be mounted vertically. The factory default zero position is with the male connector pointing down as shown in Figure 3. Sensor can be zero adjusted at any position within the full range.
- A 2-axis inclinometer must be mounted horizontally. The factory default zero position is shown in Figure 2. After installation, sensor can be zero adjusted to eliminate the mechanical offsets within a  $\pm 5^\circ$  offset range.



Figure 3 - Vertical mounting 1-axis inclination




Figure 2 - Horizontal mounting 2-axes inclination

### 4.3. Connection

The sensor is equipped with either a single 5-pole M12 (A-coded) male connector according to IEC 61076-2-101, or with an additional 5-pole M12 (A-coded) female connector. This is specified in the suffix of the device model designation: suffix CM indicates single male connector; suffix CFM indicates both a female and a male connector.

The advantage of two connectors is that devices can be daisy-chained in the CAN network. The voltage supply is forwarded from the male to the female connector, providing both power and bus-connection to the next sensor with a single cable harness. The connection between male and female connector acts as an internal T-junction.

The pin assignment is according to CiA 303-1 V1.8.0.

Pin	Assignment
Pin 1	Shield
Pin 2	Vcc
Pin 3	Gnd & CAN_GND
Pin 4	CAN_H
Pin 5	CAN_L




Figure 4 - Pin definition



- The maximum current for the internal T-junction is 2.5 A. This must be taken into account when using daisy-chained connections.
- The voltage supply must be dimensioned to prevent exceeding the specified voltage limits.
- The power consumption is about 50mA typical.
- This device must be connected to a class 2 power supply.
- Connect the sensor only to an approved CAN controller which must have a grounded shield. Alternative: connect the sensor housing to a grounded shield. All mentioned EMC standards that are met (see Declaration of Conformity) have been done with the housing connected to a grounded shield.



*Installation of wiring and the opening and closing of electrical connections must only be carried out in de-energized state! Short-circuits, voltage spikes, etc. can cause malfunctions and/or cause the installation to become uncontrolled, creating a serious risk of injury or damage to property.*



#### 4.4. CAN termination

A CAN bus should be terminated properly to prevent signal reflections. The QG65D dynamic Inclinometer has an internal 120 Ohm termination resistor. By default, this is disabled.

A separate M12 termination resistor and T-connector are available as accessories.



Figure 5 - M12 CAN terminator male 5p.  
Order code: 10217



Figure 6 - M12 CAN terminator female 5p.  
Order code: 10194



Figure 7 - M12 T-connector male 5p.  
Order code: 11822

The advantage of using a separate termination plug instead of the internal termination resistor is that an external termination plug is clearly visible. This helps to prevent an inadvertent double termination that could cause the entire CAN bus to malfunction.

#### 5. Technical data

Please refer to the datasheet of your product.

## 6. Functional description

### 6.1. Dynamic inclination measurement principle

Conventional inclinometers measure inclination by measuring g-forces using an accelerometer. In static conditions, inclination measurement by this principle is accurate and reliable. However, the vibrations or movements present on almost all industrial machines generate undesirable g-forces. These dynamic g-forces accumulate and overlay the static g-forces, causing a 'dirty' inclination output that includes spurious or noise components.

In certain applications a low-pass filter can be used to stabilize the output. The downside of this filtering is that it significantly increases the reaction time (latency) of the inclinometer. In a control system this results in a limit on the speed of movements, and reduced machine efficiency.

A gyroscope measures the speed of rotation. It therefore measures inclination perfectly in dynamic situations, but in static situations it is useless, due to bias drift.

The QG65D dynamic inclinometer combines accelerometer MEMS and gyro MEMS. This device is unaffected by vibration or movement and can therefore measure the true angle at the sensor position in real time. Our smart algorithms (such as Kalman filtering) within the device can determine the balance between the accelerometer MEMS (best result in static situations) and the gyro MEMS (best result in dynamic situations).




Figure 8 - Measurement principle of the dynamic inclinometer

## 6.2. Measuring axis and direction

### 6.2.1. Measuring axis and direction for Inclination

**A single-axis inclinometer (vertical mount)** measures the inclination in the vertical plane over the full range 0-360° (X-output). The default 0° position and the measuring direction are shown in Figure 9 - Measuring axis and direction of 1-axis inclination.



Figure 9 - Measuring axis and direction of 1-axis inclination.

**A dual-axis inclinometer (horizontal mount)** measures the inclination on both X and Y axis. Measuring range is up to 90°. Due to the measurement principle, only one axis may tilt more than 45°.





Figure 10 – Measuring axis and direction of 2-axis inclination.

 **Cross-tilt error:** when the cross axis (axis perpendicular to the measuring axis) tilts more than 45° during the measurement, the measuring axis will be disabled. The sensor will send a fixed output to indicate that the sensor is now at a cross-tilt error position ( $\rightarrow$  [Knowledgebase](#)): 20000<sub>d</sub> (200°) for the measuring range  $\pm 180^\circ$ ,  $\pm 30^\circ / \pm 90^\circ$ , and 40000<sub>d</sub> (400°) for the measuring range 0°-360°.

### 6.2.2. Measuring axis and direction for acceleration

The device measures the acceleration values on all 3 axes. The measuring direction of three axes in the factory default setting is shown in Figure 11. Raw acceleration value range are up to  $\pm 1.5/\pm 2.0$  g with resolution of 0.001g.





Figure 11 – Measuring axis and direction of acceleration

## 6.3. Signal processing



### 6.3.1. Sampling rate

Each axis of the acceleration and gyroscope MEMS is sampled by the internal microcontroller at a rate of 1000 Hz. Those samples are then processed and fed into the sensor fusion algorithm.

### 6.3.2. Sensor fusion algorithm

The sensor fusion algorithm transforms the raw MEMS outputs into a reliable inclination value. Based on the selected function mode, application profile and user-adjustable parameters, the smart algorithm will combine the accelerometer and gyroscope outputs in a balanced way optimised for your application. The limitations for the sensor fusion algorithm are: acceleration max 1.5 / 2.0 g, angular rate max. 500°/s. The calculation rate, and therefore also the output rate, is 100 Hz.

### 6.4. Boot-up procedure

When the device is powered on, the device will be initialised with the last-stored parameters. When initialisation is complete, an Address Claim Message (ACM) containing the address used and NAME will be sent. (→7.5 NAME and ACM (PGN 60928))

Bus	CAN-ID (h...)	Type	Prio.	PGN	PGN (hex)	Len...	Symbol	Data	Source	Source (hex)
1	18EEFF80	J1939	6	60928	EE00h	8	ACM	NAMEOFControllerApplication = 922533667373223231 IdentityNumber = 199999 ManufacturerCode = DIS Sensors B.V. ECUInstance = 0 FunctionInstance = 0 Function = 147 VehicleSystem = 0 VehicleSystemInstance = 0 IndustryGroup = Global, applies to all ArbitraryAddressCapable = CA is capable	128	80h

Figure 12 – example ACM at boot-up

The CAN-ID 18EEFF80 shows that the sensor has a default source address of 80<sub>h</sub>.

The data of the ACM is

Hex View: Rx, Bus 1, 18EEFF80h (ACM), DLC 8, Length 8	
0	3F 0D A3 89 00 93 00 80

Figure 13 - ACM data

This is the 64-bit device NAME for DIS sensors which contains the following fields:

MSB										64 bits										LSB									
1 bit			3 bit			4 bit			7 bit			1 bit			8 bit			5 bit			3 bit			11 bit			21 bit		
Arbitrary Address Capable			Industry group			Vehicle system Instance			Vehicle System			Reserved			Function			Function Instance			ECU Instance			Manufacturer Code			Identify Number		
1			000			0000			0000000			0			10010011			00000			000			10001001101			000110000110100111111		

Table 2 – NAME definition and data example

Bit length	Definition	Data	Meaning
21 bits	Identify Number	000110000110100111111 <sub>b</sub>	The least 21 bits of the 32-bit serial number of the sensor
11 bits	Manufacturer Code	10001001101 <sub>b</sub> = 1101 <sub>d</sub>	DIS Sensors B.V.
3 bits	ECU Instance	000 <sub>b</sub>	
5 bits	Function Instance	00000 <sub>b</sub>	
8 bits	Function	10010011 <sub>b</sub> = 147 <sub>d</sub>	Inertial Sensor
1 bit	Reserved	0 <sub>b</sub>	
7 bits	Vehicle System	0000000 <sub>b</sub>	
4 bits	Vehicle system Instance	0000 <sub>b</sub>	
3 bits	Industry group	000 <sub>b</sub>	Global, applies to all industries
1 bit	Arbitrary Address	1 <sub>b</sub>	yes

Table 3 - NAME explanation

## 6.5. Output format

The device supports 2 different parameter groups (Tx PGNs):

- Proprietary B Tx PGN1 65280 for Longitudinal, Lateral Inclination (Availability of lateral information depends on sensor type)
- Proprietary B Tx PGN2 65283 for X, Y, Z Acceleration

### 6.5.1. Inclination outputs PGN 65280 (FF00h).

PGN	Name	Priority	SPN position(bit)	SPN Width(bit)	Resolution	Offset	Data Range
65280 <sub>d</sub> FF00 <sub>h</sub>	X axis (Longitudinal)	3	0	16	0.01°/bit	-	-90° - +90°
	Y axis (Lateral)	3	16	16	0.01°/bit	-	-90° - +90°

Table 4 – Transmit PGN1 inclination 2-axis

PGN	Name	Priority	SPN position(bit)	SPN Width(bit)	Resolution	Offset	Data Range
65280 <sub>d</sub> FF00 <sub>h</sub>	X axis (Longitudinal)	3	0	16	0.01°/bit	-	-180° - +180°

Table 5 - Transmit PGN1 inclination 1-axis

The angle can be calculated with formula:  $\alpha = \text{J1939 output} / 100$ . ( $\alpha$  = angle in degrees, factory resolution is 0.01°)




Figure 14 - Output 1-axis ±180° sensor




Figure 15 - Output 2-axis ±90° sensor




Figure 16 - Output 2-axis ±30° sensor

Example – Inclination output of a 1-axis sensor.

Time (rel.)	Bus	ID (hex.)	Symbol	Rx/Tx	Type	Prio	PGN	SA	DA	Length	Data (hex.)
0,1217	1	0CFF0080	Inclination Output	Rx	Data	3	65280	128	255	8	0A 0A FF FF FF FF FF FF
0,2217	1	0CFF0080	Inclination Output	Rx	Data	3	65280	128	255	8	30 0A FF FF FF FF FF FF
0,3217	1	0CFF0080	Inclination Output	Rx	Data	3	65280	128	255	8	44 0A FF FF FF FF FF FF

The first 2 bytes are the angle value, the rest 6 bytes are not used..

Byte0	Byte1
0Ah	0Ah
Inclination output: 0A0Ah = 2570 <sub>d</sub> = 25.70°	

Table 6 - Output 1-axis ±180° sensor explanation

Example – Inclination output of a 2-axis sensor

Time (diff.)	Bus	ID (hex.)	Symbol	Rx/Tx	Type	Prio	PGN	SA	DA	Length	Data (hex.)
-	1	00FF0080	Inclination Output	Rx	Data	0	65280	128	255	8	8E FC 4B 08 FF FF FF FF
0,1000	1	00FF0080	Inclination Output	Rx	Data	0	65280	128	255	8	F4 FB 7A 08 FF FF FF FF

The first 2 bytes are X inclination, and the second 2 bytes are Y inclination. The rest 4 bytes are not used.

Byte0	Byte1	Byte2	Byte3
<b>X inclination</b>		<b>Y inclination</b>	
8E <sub>h</sub>	FC <sub>h</sub>	4B <sub>h</sub>	08 <sub>h</sub>
FC8E <sub>h</sub> = -882 <sub>d</sub> = -8.82°		084B <sub>h</sub> = 2123 <sub>d</sub> = 21.23°	

Table 7 – Output 2-axis 90° sensor explanation

6.5.2. Acceleration outputs PGN 65283 (FF03h).

PGN	Name	Priority	SPN position(bit)	SPN Width(bit)	Resolution	Offset	Data Range
<b>65283<sub>d</sub></b>	X axis (Longitudinal)	3	0	16	0.001g/bit	-	H series: -1.5g to +1.5g Std. series: -2.0g to +2.0g
<b>FF03<sub>h</sub></b>			16	16	0.001g/bit	-	H series: -1.5g to +1.5g Std. series: -2.0g to +2.0g
			32	16	0.001g/bit	-	H series: -1.5g to +1.5g Std. series: -2.0g to +2.0g

Table 8 - Transmit PGN2 acceleration

Acceleration can be calculated with formula:  $a = \text{J1939 output} / 1000$ . (a = acceleration in g, factory resolution is 0.001g)




Figure 17 - Output acceleration high accuracy series




Figure 18 - Output acceleration std. accuracy series

For example:

Time (diff.)	Bus	ID (hex.)	Symbol	Rx/Tx	Type	Prio	PGN	SA	DA	Length	Data (hex.)
-	1	00FF0380	Acceleration Output	Rx	Data	0	65283	128	255	8	EA FF 0A 00 18 FC FF FF
0,1000	1	00FF0380	Acceleration Output	Rx	Data	0	65283	128	255	8	EA FF 0A 00 18 FC FF FF

Figure 19 - Acceleration output trace

The 6 bytes data are defined as below.

Byte0	Byte1	Byte2	Byte3	Byte4	Byte5
<b>X acceleration</b>		<b>Y acceleration</b>		<b>Z acceleration</b>	
EA <sub>h</sub>	FF <sub>h</sub>	0A <sub>h</sub>	00 <sub>h</sub>	18 <sub>h</sub>	FC <sub>h</sub>
FFEA <sub>h</sub> = -22 <sub>d</sub> = -0.022g		000A <sub>h</sub> = 10 <sub>d</sub> = 0.010g		FC18 <sub>h</sub> = -1000 <sub>d</sub> = -1.000g	

### 6.6. Sensor configuration (PGN 61184)

For reading and writing the sensor configuration, Prop A PGN 61184 (EF00<sub>n</sub>) (->PGN (Parameter Group Number)) is used.

Example – Read serial number.




Figure 20 - CMD read serial number

The 8 bytes data are defined as below:

D0	D1	D2	D3	D4	D5	D6	D7										
Object Index		CMD	Sub index /Status	Data0	Data1	Data2	Data3										
<b>Object index</b>	Index of the PGN object. (→ 8 Object overview)																
<b>CMD</b>	01 <sub>h</sub> = Command for read data 02 <sub>h</sub> = Command for write data																
<b>Sub Index:</b>	message to the sensor: Sub index of the PGN object. (→ 8 Object overview) message from the sensor: Status reply																
			<table border="1"> <thead> <tr> <th>Message</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>00<sub>h</sub></td> <td>Ok processing successfully</td> </tr> <tr> <td>F0<sub>h</sub></td> <td>Invalid index</td> </tr> <tr> <td>F1<sub>h</sub></td> <td>Invalid parameter, parameter out of range</td> </tr> <tr> <td>F2<sub>h</sub></td> <td>EEPROM error</td> </tr> </tbody> </table>					Message	Description	00 <sub>h</sub>	Ok processing successfully	F0 <sub>h</sub>	Invalid index	F1 <sub>h</sub>	Invalid parameter, parameter out of range	F2 <sub>h</sub>	EEPROM error
Message	Description																
00 <sub>h</sub>	Ok processing successfully																
F0 <sub>h</sub>	Invalid index																
F1 <sub>h</sub>	Invalid parameter, parameter out of range																
F2 <sub>h</sub>	EEPROM error																
<b>Data0 to Data3</b>	0 to 4 data bytes (Number of valid bytes depends on the object)																

Table 9 - PGN 61184 data definition

More configuration examples can be found in 9 Configuration examples.



### 6.7. Load factory default settings

Factory reset or load factory default settings allows users to restore the device to its original manufacturer settings. The customer settings which were saved to the EEPROM will be overwritten by the factory default settings.

With [object 1011<sub>h</sub>](#), the factory default settings below can be restored. Customised products may have different factory default values, which may deviate from this manual. See the datasheet of your customized products for these customized factory default values.

#### DIS factory default

Parameters	Object	DIS standard default value
Device Address	3101 <sub>h</sub>	80 <sub>h</sub>
Baud Rate	3001 <sub>h</sub>	03 <sub>h</sub> - 250 kBit/s
PGN1 (65280)	3102 <sub>h</sub>	Cycle time = 100 <sub>d</sub> = Enabled
PGN2 (65283)	3103 <sub>h</sub>	Cycle time = 0 <sub>d</sub> = Disabled
Application profile	3001	01 = Profile 1 Dynamic (fast mode)

Table 10 – DIS standard factory default communication parameters

Procedures:



- Write "load" to sub-index 01<sub>h</sub> = All parameters will be restored.
- Write "load" in ASCII or "64616F6Ch" have the same effect.

Example:

Figure 21 - Restore default settings



## 6.8. Zero adjustment

Zero adjustment allows users to compensate for mechanical offsets of a horizontally mounted 2-axis device or set a customised 0° position of a vertically mounted 1-axis sensor. The measured inclination value at the 0° position will be stored in the device as a permanent offset, which is used to calculate the actual inclination output of the device. The zero offset value can be read from Object 6013<sub>h</sub>, 6023<sub>h</sub>.

Zero adjustment can be done in two ways and can be repeated at any time.

### 1. Via Object 300F<sub>h</sub> Zero adjustment.

To perform a zero adjustment, write the corresponding value to object 300F<sub>h</sub> subindex 00<sub>h</sub>. The zero adjustment can be done for each axis separately or for all axes at the same time. Status information of the result is available from object 300F<sub>h</sub>.

Value		Response
01 <sub>h</sub>	Start zero adjustment X-axis - inclination	00 <sub>h</sub> = Successful; FF <sub>h</sub> = Failed
02 <sub>h</sub>	Start zero adjustment Y axis - inclination	00 <sub>h</sub> = Successful; FE <sub>h</sub> = Failed
03 <sub>h</sub>	Start zero adjustment X and Y axis - inclination	00 <sub>h</sub> = Successful; FD <sub>h</sub> = Failed

Table 11 - Definition object 300F<sub>h</sub>

For example:

Write 03<sub>h</sub> to zero both X and Y axis.

The screenshot shows a configuration tool with the following fields:
 

- ID: (hex) 0CEF8000
- Length: 8
- Data: (hex) 0F 30 02 00 03 00 00 00
- PGN: (hex) EF00
- Priority: 3
- Source: 00h
- Destination: 80h
- Hexadecimal Values

Figure 22 - commands to zero both X and Y axis

```
Hex View: Rx, Bus 1, 00EF0080h (PropA), DLC 8, Length 8
0 0F 30 01 00 00 00 00
```

Figure 23 - response from the sensor indicating that zero is successful (data=00)

Bus	CAN-ID (h...)	Type	Prio.	PGN	PGN (hex)	Len...	Symbol	Data
1	0CFF0080	J1939	3	65280	FF00h	8	Inclination Output	Long = 0,00 deg lateral = 0,00 deg

Figure 24 - sensor live output

If the sensor is zeroed at an illegal position, the response (byte4) will be FF/FE/FD<sub>h</sub>

```
Hex View: Rx, Bus 1, 00EF0080h (PropA), DLC 8, Length 8
0 0F 30 01 00 FD 00 00
```

Figure 25 - response shows that zero at X and Y axis both failed.

The offset value will be stored permanently in the device without "save" to object 1010<sub>h</sub>.

2. Via Object 6012h, 6022h Pre-set inclination value.

To set the output of X/Y axis to 0°, write 0000h to object 6012h / 6022h at your desired 0° position. The offset will be stored in Object 6012h, 6022h . Those parameters must be saved to the device.

Index	Sub-index	Definition	Value Example
6012h	00h	Pre-set inclination X-axis	0000 <sub>d</sub> - 0°
6022h	00h	Pre-set inclination Y axis	0100 <sub>d</sub> - 1°

Table 12 - Object 6012/6022h definition

Example - Pre-set the X axis to 0°

ID: (hex) Length: Data: (hex)

0CEF8000 8 12 60 02 00 00 00 00 ...

0 1 2 3 4 5 6 7

Figure 26 - commands to pre-set X axis to 0°

```
Hex View: Rx, Bus 1, 00EF0080h (PropA), DLC 8, Length 8
0 12 60 02 00 00 00 00
```

Figure 27 - response from the sensor indicating pre-set is successful (Byte3=00h)

Bus	CAN-ID (h...)	Type	Prio.	PGN	PGN (hex)	Len...	Symbol	Data
1	0CFF0080	J1939	3	65280	FF00h	8	Inclination Output	Long = 0,00 deg lateral = -6,23 deg

Figure 28 - sensor live output shows that The X axis is zeroed

When an out-of-range pre-set value is sent, the sensor sends “F1” as response indicating “Invalid parameter, parameter out of range” (->6.6 Sensor configuration)

ID: (hex) Length: Data: (hex)

0CEF8000 8 12 60 02 00 94 11 00 ...

0 1 2 3 4 5 6 7

Figure 29 - pre-set X angle to 1194h/45°

```
Hex View: Rx, Bus 1, 00EF0080h (PropA), DLC 8, Length 8
0 12 60 02 F1 94 11 00
```

Figure 30 - response from sensor indicating that pre-set is failed. (Byte3=F1h)

1-axis ±180° sensors can be zero adjusted over the full range, the position of the male connector is at customer discretion.  
2-axis ±30°/±90° sensors can only be zero adjusted in a horizontal position within an offset limit of ±5°.

After you load factory default settings, the sensor will be restored with the factory zero offset, which means the pre-set inclination value will be restored to 00h, object 6013h and 6023h will be rewritten to a factory default value and you need to zero your sensor again.

## 6.9. Firmware management

The factory-installed firmware version is stated on the device label.




Figure 31 - Firmware version

It can also be requested with object 100A<sub>h</sub> sub-index 00<sub>h</sub> Manufacturer software version. The message format is “Vx.x.x” in ASCII, for example: V1.0.0.



The firmware release notes are available at [www.dis-sensors.com](http://www.dis-sensors.com) under “downloads/user manuals”.

## 7. SAE J1939 specification

The QG65D J1939 series of devices communicates with the SAE J1939 interface. SAE J1939 uses the CAN protocol to transmit a message on the network. Every message includes an identifier which defines the message priority, who sent it, and what data is contained within it.

More knowledge of J1939 can be found in our [Knowledgebase](#).

### 7.1. PDU (Protocol Data Unit)

The Protocol Data Unit provides a framework for organizing the key information that is sent with every CAN data frame.

PDU format												
SOE	Identifier	SRR	IDE	Identifier	RTR	r1	r0	DLC	Data	CRC	ACK	EOF + IFS
1 bit	11 bits	1 bit	1 bit	18 bits	1 bit	2 bits		4 bits	0 - 8*8 bits	16 bits	2 bits	10 bits

Figure 32 - J1939 PDU format

### 7.2. CAN-ID (CAN Identifier)

PDU format												
SOE	Identifier	SRR	IDE	Identifier	RTR	r1	r0	DLC	Data	CRC	ACK	EOF + IFS
1 bit	11 bits	1 bit	1 bit	18 bits	1 bit	2 bits		4 bits	0 - 8*8 bits	16 bits	2 bits	10 bits

29-bit CAN-ID																						
28			25								8	7										0
priority			Parameter Group Number (PGN)															Source Address (SA)				

Table 13 - CAN-ID definition

<b>Priority (3 bits)</b>	Message priority during the arbitration process. 0= high and 7=low. Not used by receiver.
<b>PGN (18 bits)</b>	The PGN uniquely identifies the parameter group (PG) that is being transmitted in the message.
<b>SA (8 bits)</b>	This field defines the specific address to which the message is being sent. All other destinations should ignore this message. In the case of the global destination address (255), all devices are required to listen and respond as message recipients

Table 14 - CAN-ID explanation

0CFF0080h

28			25																				8	7											0
0	1	1	0	0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
priority = 3			Parameter Group Number (PGN) = 0FF00 <sub>h</sub>															Source Address (SA) = 80 <sub>h</sub>																	

Figure 33 - Example CAN-ID of inclination output



18	17	16						8	7							0
EDP DP		PDU Format 1(PF) < 240						Destination Address (DA)								
18	17	16						8	7							0
EDP DP		PDU Format 2 (PF) >= 240						Group Extension								

**DA:** defines the specific address to which the message is being sent.  
**GE:** provides extra 4096 PGNs per data page.

Table 15 - PGN definition

PGNs used by DIS J1939 sensors are explained as below:

PGN	PG Name	J1939 Definition	DIS
<b>61184<sub>d</sub></b> <b>(00EF00<sub>h</sub>)</b>	PropA	This PG uses the destination-specific PDU1 Format allowing manufacturers to direct their proprietary communications to a specific destination node. How the Data field of this message is used is up to each manufacturer.	Sensor configuration is sent with PGN 61184
<b>65280<sub>d</sub></b> <b>(00FF00<sub>h</sub>)</b>	PropB	This PG uses the PDU2 Format message allowing manufacturers to define the PS (GE) field content as they desire.	Inclination output is sent by PGN 65280.
<b>65283<sub>d</sub></b> <b>(00FF03<sub>h</sub>)</b>	PropB	This PG uses the PDU2 Format message allowing manufacturers to define the PS (GE) field content as they desire.	Acceleration output is sent by PGN 65283.
<b>60928<sub>d</sub></b> <b>(00EE00<sub>h</sub>)</b>	AC	The Address Claimed PGN may be used in two ways: to claim an address, and to announce that a CA was unable to claim an address.	ACM
<b>59904<sub>d</sub></b>	Request Message	The request message (PGN 59904) for the Address Claimed message (PGN 60928) is used by any CA to request the NAMEs and addresses of CAs in ECUs attached to the network.	RQST

Table 16 - PGN examples

### 7.4. SPN (Suspect Parameter Number)

SPN is a 19-bit identifier for the CAN signals (parameters) contained in the data. SPNs are grouped by PGNs and can be described in terms of their bit start position, bit length, scale, offset and unit - information required to extract and scale the SPN data to physical values.

The assignment of SPNs can be found in SAE J1939-21 documents. DIS sensors B.V. is using PGN 2551 for definition of inclination and acceleration outputs.

	PGN 65280 to 65535 Proprietary B	Manufacturer Defined Usage (PropB_PDU2)	2551	64 to 14280
--	-------------------------------------	--	------	----------------

Example – SPN 2551 by PGN 65280 Inclination output defined by DIS Sensors B.V.

PGN	Name	Priority	Position in PG	Bit Size	Resolution (scale)	Offset	Data Range
<b>65280<sub>d</sub></b>	X axis (Longitudinal)	3	0	16	0.01°/bit		-90° - +90°
<b>FF00<sub>h</sub></b>	Y axis (Lateral)		16	16	0.01°/bit		-90° - +90°

### 7.5. NAME and ACM (PGN 60928)

Every device shall have one address and an associated **NAME** to communicate on the SAE J1939 network.

SAE J1939 defines a 64-bit NAME to identify the primary function of a controller application. The NAME consists of fields shown in table below.

MSB		64 bits						LSB	
1 bit	3 bit	4 bit	7 bit	1 bit	8 bit	5 bit	3 bit	11 bit	21 bit
Arbitrary Address Capable	Industry group	Vehicle system Instance	Vehicle System	Reserved	Function	Function Instance	ECU Instance	Manufacturer Code	Identify Number

Table 17 - NAME format

**Address Claim**, defined in SAE J1939-81, is the process for claiming a network address and associating the NAME, or vehicle function, to that address.

Upon power-up or whenever requested, a device must send an ACM to claim an address. Other devices must compare the newly claimed address with their own to avoid conflicts. When multiple devices claim the same address, the device with lower NAME value uses the address, the others must claim a different address or stop communicating on the network.

A device can send request for the ACM to determine whether addresses claimed by other devices. PGN 59904 (RQST) for ACM (PGN 60928) is described as below:



ID: (hex)	Length:	Data: (hex)			
18EAFFFE	3	00	EE	00	...
		0	1	2	
PGN: (hex)	Priority:	Source:	Destination:		
EA00	6	Null	Global		
<input checked="" type="checkbox"/> Hexadecimal Values					

All requested devices send their ACMs so that you know which devices are currently on the network.

Any CA that is unable to successfully claim an address shall respond with a Cannot Claim Address message. It has the same PGN as ACM but has a source address of 254d (the NULL address).

## 8. Object overview

Some CAN open objects are kept for J1939 sensors for the configuration purpose. Use PGN 61184 to read/write those objects. (→ 6.6 Sensor configuration (PGN 61184))

Index	Subindex	Data Type	Access	Object Name and description	Factory Default	Detail		
1000 <sub>h</sub>	00 <sub>h</sub>	U32	r	<b>Device type</b>	0101019A <sub>h</sub> – 1-axis inclination 0102019A <sub>h</sub> – 2-axis inclination			
1008 <sub>h</sub>	00 <sub>h</sub>	VSTR	const	<b>Manufacturer device name</b>				
1009 <sub>h</sub>	00 <sub>h</sub>	VSTR	const	<b>Manufacturer hardware version</b>	Depends on sensor. E.g. "V8.00"			
100A <sub>h</sub>	00 <sub>h</sub>	VSTR	const	<b>Manufacturer software version</b>	Depends on sensor. E.g. "V1.0.0"			
1010 <sub>h</sub>	01 <sub>h</sub>			<b>Save all parameters</b> Write "save" or "65766173 <sub>h</sub> "		9.4		
1011 <sub>h</sub>	01 <sub>h</sub>			<b>Restore all parameters</b> Write "load" or "64616F6C <sub>h</sub> "				
1018 <sub>h</sub>				<b>Identity object</b>				
	00 <sub>h</sub>	U8	const	Highest subindex supported	04 <sub>h</sub>			
	01 <sub>h</sub>	U32	r	Vendor ID	000001BD <sub>h</sub>			
	02 <sub>h</sub>	U32	r	Product code	08000001 <sub>h</sub> – 1-axis inclination 360° 08000002 <sub>h</sub> – 2-axes inclination ±90° 08000003 <sub>h</sub> – 2-axes inclination ±30°			
	03 <sub>h</sub>	U32	r	Revision number	00010000 <sub>h</sub> – V1.0.0			
04 <sub>h</sub>	U32	r	Serial number					
3001 <sub>h</sub>	00 <sub>h</sub>	U8	rw	<b>Baud Rate</b> 02 <sub>h</sub> = 500 kBit/s 03 <sub>h</sub> = 250 kBit/s	03 <sub>h</sub>			
3003 <sub>h</sub>	00 <sub>h</sub>	U8	rw	<b>CAN bus termination resistor 120Ω</b> 00 <sub>h</sub> = Disable 01 <sub>h</sub> = Enable	00 <sub>h</sub>			
300F <sub>h</sub>	00 <sub>h</sub>	U8	rw	<b>Zero adjustment Inclination</b>				
				01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed		
				02 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FE=failed		
				03 <sub>h</sub>	Zero X and Y axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed		
				<b>Zero adjustment Acceleration</b>				
				01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed		
				02 <sub>h</sub>	Zero Y-axis	00 <sub>h</sub> =successful FE=failed		
				03 <sub>h</sub>	Zero Z-axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed		
				07 <sub>h</sub>	Zero all axis	00 <sub>h</sub> =successful F9 <sub>h</sub> =failed		
3101 <sub>h</sub>	00 <sub>h</sub>	U8	rw	<b>J1939 Address</b> (Range: 0 <sub>d</sub> – 254 <sub>d</sub> )	80 <sub>h</sub>			

Index	Subindex	Data Type	Access	Object Name and description	Factory Default	Detail
3102 <sub>h</sub>				<b>PGN 65280 Angle output</b>		
	01 <sub>h</sub>	U32	r	Priority (range: 0-7)	03 <sub>h</sub>	
	02 <sub>h</sub>	U32	r	Cycle time [ms] 0 = deactivated	0064 <sub>h</sub> = 100ms	
3103 <sub>h</sub>				<b>PGN 65283 Acceleration output</b>		
	01 <sub>h</sub>	U32	r	Priority (range: 0-7)	03 <sub>h</sub>	
	02 <sub>h</sub>	U32	r	Cycle time [ms] 0 – deactivated	0064 <sub>h</sub> = 100ms	
6000 <sub>h</sub>	00 <sub>h</sub>	U16	r	<b>Resolution</b> 1 <sub>d</sub> =0.001, 10 <sub>d</sub> =0.01, 100 <sub>d</sub> =0.1, 1000 <sub>d</sub> =1.0	10 <sub>d</sub>	
6012 <sub>h</sub>	00 <sub>h</sub>	S16	rw	<b>Pre-set Inclination X-axis</b>	0000 <sub>h</sub>	
6013 <sub>h</sub>	00 <sub>h</sub>	S16	rw	<b>Offset Inclination X-axis</b>	0000 <sub>h</sub>	
6022 <sub>h</sub>	00 <sub>h</sub>	S16	rw	<b>Pre-set Inclination Y-axis</b>	0000 <sub>h</sub>	
6023 <sub>h</sub>	00 <sub>h</sub>	S16	rw	<b>Offset Inclination Y-axis</b>	0000 <sub>h</sub>	



To permanently save communication parameters in the EEPROM of the device, use only CAN Object 1010<sub>h</sub>, otherwise the changes will be lost after a power cycle. All indices and/or subindices not described in the table are reserved exclusively for factory use.

Data types used in the application layers are explained in the following table.

Data type	Definitions
<b>U8</b>	Unsigned 8-bit number (0 – 255 <sub>d</sub> )
<b>U16</b>	Unsigned 16-bit number (0 – 65535 <sub>d</sub> )
<b>U32</b>	Unsigned 32-bit number (0 – 4294967295 <sub>d</sub> )
<b>S8/Integer 8</b>	Signed integer 8-bit number (-128 <sub>d</sub> – +127 <sub>d</sub> )
<b>S16/Integer 16</b>	Signed integer 16-bit number (-32768 <sub>d</sub> – +32767 <sub>d</sub> )
<b>S32/Integer 32</b>	Signed integer 16-bit number (-2147483648 <sub>d</sub> – +2147483647 <sub>d</sub> )
<b>VSTR</b>	Visible String

Table 18 - Data type

## 9. Configuration examples

### 9.1. Change device address

Use object 3101<sub>h</sub> sub-index 00<sub>h</sub> to change the device address.

ID: (hex)	Length:	Data: (hex)								
OCEF0000	8	01	31	02	00	80	00	00	00	...
		0	1	2	3	4	5	6	7	
PGN: (hex)	Priority:	Source:	Destination:							
EF00	3	00h	00h							
<input checked="" type="checkbox"/> Hexadecimal Values										

Byte 0-1	Object index = 3101 <sub>h</sub>
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 00 <sub>h</sub>
Byte 4	New Device address = 80 <sub>h</sub>
Byte 5-7	00 = Not used

### 9.2. Change baud rate

Use object 3001<sub>h</sub> sub-index 00<sub>h</sub> to change the baud rate.

ID: (hex)	Length:	Data: (hex)								
OCEF8000	8	01	30	02	00	03	00	00	00	...
		0	1	2	3	4	5	6	7	
PGN: (hex)	Priority:	Source:	Destination:							
EF00	3	00h	80h							
<input checked="" type="checkbox"/> Hexadecimal Values										

Byte 0-1	Object index = 3001 <sub>h</sub>
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 00 <sub>h</sub>
Byte 4	03 <sub>h</sub> = 250 kbit/s 02 <sub>h</sub> = 500 kbit/s
Byte 5-7	00 = Not used

### 9.3. Enable/Disable PGNs

Use PGN cycle time to enable or disable PGNs. Object 3102<sub>h</sub> is used for PGN 65280 and object 3103<sub>h</sub> is used for PGN 65283. Below is an example for PGN 65280.

ID: (hex)	Length:	Data: (hex)							
OCEF8000	8	02	31	02	02	64	00	00	00
		0	1	2	3	4	5	6	7
PGN: (hex)	Priority:	Source:	Destination:						
EF00	3	00h	80h						
<input checked="" type="checkbox"/> Hexadecimal Values									

Byte 0-1	Object index = 3102 <sub>h</sub> (object used for PGN 65280)
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 02 <sub>h</sub>
Byte 4	PGN cycle time = 64 <sub>h</sub> = 100ms Setting PGN cycle time to a non-zero value will enable PGN
Byte 5-7	00 = Not used

Table 19 - Example enable PGN 65280

#### Disable PGN

ID: (hex)	Length:	Data: (hex)							
OCEF8000	8	02	31	02	02	00	00	00	00
		0	1	2	3	4	5	6	7
PGN: (hex)	Priority:	Source:	Destination:						
EF00	3	00h	80h						
<input checked="" type="checkbox"/> Hexadecimal Values									

Byte 0-1	Object index = 3102 <sub>h</sub>
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 02 <sub>h</sub>
Byte 4	PGN cycle time = 00 <sub>h</sub> Setting PGN cycle time to zero will disable PGN
Byte 5-7	00 = Not used

Table 20 - Example disable PGN 65280

### 9.4. Save changes to the sensor

Use object 1010<sub>h</sub> sub-index 01<sub>h</sub>

ID: (hex)	Length:	Data: (hex)								
0CEF0000	8	10	10	02	01	73	61	76	65	...
		0	1	2	3	4	5	6	7	
PGN: (hex)	Priority:	Source:	Destination:							
EF00	3	00h	00h							
<input checked="" type="checkbox"/> Hexadecimal Values										

Byte 0-1	Object index = 1010 <sub>h</sub>
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 01 <sub>h</sub>
Byte 4-7	Write 65766173 <sub>h</sub> (save)

### 9.5. Restore factory default

Use object 1011<sub>h</sub> sub-index 01<sub>h</sub>

ID: (hex)	Length:	Data: (hex)								
0CEF8000	8	11	10	02	01	6C	6F	61	64	...
		0	1	2	3	4	5	6	7	
PGN: (hex)	Priority:	Source:	Destination:							
EF00	3	00h	80h							
<input checked="" type="checkbox"/> Hexadecimal Values										

Byte 0-1	Object index = 1011 <sub>h</sub>
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor.
Byte 3	Object sub index = 01 <sub>h</sub>
Byte 4-7	Write 64616F6C <sub>h</sub> (load)

### 9.6. Read vendor ID

Vendor ID can be read by object 1018<sub>h</sub> sub-index 01<sub>h</sub>

ID: (hex)	Length:	Data: (hex)								
0CEF8000	8	18	10	01	01	00	00	00	00	...
		0	1	2	3	4	5	6	7	
PGN: (hex)	Priority:	Source:	Destination:							
EF00	3	00h	80h							
<input checked="" type="checkbox"/> Hexadecimal Values										

Byte 0-1	Object index = 1018 <sub>h</sub>
Byte 2	CMD = 01 <sub>h</sub> , read sensor
Byte 3	Object sub index = 01 <sub>h</sub>
Byte 4-7	00 <sub>h</sub> = Not used

The status reply from the sensor is

Hex View: Rx, Bus 1, 00EF0080h (PropA), DLC 8, Length 8

0 18 10 01 00 BD 01 00 00

Byte 0-1	Object index = 1018 <sub>h</sub>
Byte 2	CMD = 01 <sub>h</sub> , read sensor
Byte 3	Status reply = 00 <sub>h</sub> = Read successful
Byte 4-7	Data = 000001BD <sub>h</sub> = DIS Sensors B.V.

### 9.7. Zero adjustment

Use object 300F<sub>h</sub> sub-index 00<sub>h</sub> to zero the sensor. Below is an example of zeroing X and Y axis for a 2-axis sensor.

ID: (hex)	Length:	Data: (hex)	
0CEF8000	8	0F 30 02 00 03 00 00 00 ...	
		0 1 2 3 4 5 6 7	
PGN: (hex)	Priority:	Source:	Destination:
EF00	3	00h	80h
<input checked="" type="checkbox"/> Hexadecimal Values			

Byte 0-1	Object index = 300F <sub>h</sub>																					
Byte 2	CMD = 02 <sub>h</sub> , write to the sensor																					
Byte 3	Sub-index = 00 <sub>h</sub>																					
Byte 4-7	<p>Data = 03<sub>h</sub> = Inclination Zero adjustment for X and Y axis.</p> <p><b>Zero adjustment Inclination</b></p> <table> <tr> <td>01<sub>h</sub></td> <td>Zero X-axis</td> <td>00<sub>h</sub>=successful FF<sub>h</sub>=failed</td> </tr> <tr> <td>02<sub>h</sub></td> <td>Zero Y-axis</td> <td>00<sub>h</sub>=successful FE=failed</td> </tr> <tr> <td>03<sub>h</sub></td> <td>Zero X and Y axis</td> <td>00<sub>h</sub>=successful FD<sub>h</sub>=failed</td> </tr> </table> <p><b>Zero adjustment Acceleration</b></p> <table> <tr> <td>01<sub>h</sub></td> <td>Zero X-axis</td> <td>00<sub>h</sub>=successful FF<sub>h</sub>=failed</td> </tr> <tr> <td>02<sub>h</sub></td> <td>Zero Y-axis</td> <td>00<sub>h</sub>=successful FE=failed</td> </tr> <tr> <td>03<sub>h</sub></td> <td>Zero Z-axis</td> <td>00<sub>h</sub>=successful FD<sub>h</sub>=failed</td> </tr> <tr> <td>07<sub>h</sub></td> <td>Zero all axis</td> <td>00<sub>h</sub>=successful F9<sub>h</sub>=failed</td> </tr> </table>	01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed	02 <sub>h</sub>	Zero Y-axis	00 <sub>h</sub> =successful FE=failed	03 <sub>h</sub>	Zero X and Y axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed	01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed	02 <sub>h</sub>	Zero Y-axis	00 <sub>h</sub> =successful FE=failed	03 <sub>h</sub>	Zero Z-axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed	07 <sub>h</sub>	Zero all axis	00 <sub>h</sub> =successful F9 <sub>h</sub> =failed
01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed																				
02 <sub>h</sub>	Zero Y-axis	00 <sub>h</sub> =successful FE=failed																				
03 <sub>h</sub>	Zero X and Y axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed																				
01 <sub>h</sub>	Zero X-axis	00 <sub>h</sub> =successful FF <sub>h</sub> =failed																				
02 <sub>h</sub>	Zero Y-axis	00 <sub>h</sub> =successful FE=failed																				
03 <sub>h</sub>	Zero Z-axis	00 <sub>h</sub> =successful FD <sub>h</sub> =failed																				
07 <sub>h</sub>	Zero all axis	00 <sub>h</sub> =successful F9 <sub>h</sub> =failed																				

## 10. Abbreviations and definitions

<b>ACM</b>	Address Claimed Message
<b>CAN</b>	Controller Area Network
<b>CAN-ID</b>	CAN Identifier
<b>PGN</b>	Parameter Group Number
<b>PDU</b>	Protocol Data Unit
<b>SPN</b>	Suspect Parameter Number
<b>MEMS</b>	Microelectromechanical system
<b>DOF</b>	Degrees of freedom
<b>PropA</b>	Proprietary A, PGN 61184
<b>PropB</b>	Proprietary B

## 11. Normative references

<b>ISO11898-1</b>	Controller area network (CAN) —Data link layer and physical signalling
<b>ISO11898-2</b>	Controller area network (CAN) —High-speed medium access unit
<b>SAE J1939</b>	SAE’s family of standards relating to the Controller Area Network (CAN) for heavy-duty vehicles.
<b>IEC 61076-2-101</b>	Connectors for electronic equipment - Part 2-101: Circular connectors – Detail specification for circular connectors M8 with screw- or snap-locking, M12 with screw locking for low voltage applications